

ERROR CODES	DESCRIPTION
01	The coffee grinder is blocked
02	The grinder is disconnected (Only coffee grinder without electronic sensor)
03	The brewing unit is blocked in work position
04	The brewing unit is blocked in home position
05	The hydraulic circuit is clogged
10	The temperature sensor is in short circuit
11	The temperature sensor is opened
14	The temperature was up to 170°
15	The machine doesn't heat up
19	The net is not stable
22	The keyboard is not recognized