

CODE	Description	NOTES
01	Grinder fail	
02	The grinder is disconnected (Only coffee grinder without electronic sensor)	
03	Bu movement toward WORK fail	
04	Bu movement toward HOME fail	
05	Water circuit fail	
10	NTC short circuit fail	
11	NTC open circuit fail	
14	Heater over-temperature fail	
15	Heater time-out fail	
19	Zero-Crossing fail	